

Please observe the do's and don'ts to avoid damage to this system.


Don't use the following fixings they are strictly forbidden on this system:

- ▼ nails
- ▼ screws
- ▼ pins
- ▼ staples
- ▼ paint


Do use;

- ▼ double sided tabs
- ▼ velcro hooks and loop
- ▼ panel brackets
- ▼ hanging chains for heavy exhibits

Basic Shell Scheme




Shell Dimensions




Ceiling Grid Layout

Ceiling beams start 2 metres out from the corner post (or left hand post if open on one side) and run every 2 metres, diagonally.


A post is added for stability on stands over 4 metres in length




Posters and Panels




Panel Dimensions




Post Section



Beam Section



If you have any questions or queries regarding your shell scheme stand then please do not hesitate to contact us. We will be happy to help.



- ▼ Brand new white Octanorm system
- ▼ White panels, each 950mm wide x 2500mm high
- ▼ White fascia panel with 'company name'
- ▼ Carpet - colours may vary at Venues